


TINOS 2FBAL-OTR



* +/- 4 cm



D – Montageanleitung

GB – Assembly instructions

NL – Handleiding voor de montage

PL – Instrukcja montażu

TR – Montaj talimatı

RU – Инструкция по монтажу

RO – Instrucțiuni de montaj



IT – Istruzioni di montaggio


FR – Notice de montage



SK – Návod na montáž



CZ – Montážní návod


HU – Szerelési útmutató

 A FI 50 H-50 - 16	 B 5x40 - 16	 C FI 30 - 16	 D M6x45 - 4	 E x2	 F x2
---	--	---	--	--	---



1			 A FI 50 H-50-6	 B 5x40 - 6	 C FI 30 - 6
----------	---	---	--	--	---





2			 A FI 50 H-50-4	 B 5x40 - 4	 C FI 30 - 6
----------	---	---	--	--	---



3			 A FI 50 H-50-2	 B 5x40 - 2	 C FI 30 - 2
---	--	--	---------------------------	-----------------------	------------------------




4			 A FI 50 H-50-4	 B 5x40 - 4	 C FI 30 - 4
---	--	--	---------------------------	-----------------------	------------------------




5


D M6x45 - 4




6




7




8





9



9a








9b




TINOS 2FBAL-OTR

TINOS OTL-2FBAR



2



2a



3



G



M6x20 - 4








4






G








M6x20 - 4



5




G M6x20 - 4


6


G M6x20 - 4


8






H M6x45 - 4

9





H M6x45 - 4



7






H M6x45 - 4




10



H M6x45 - 4




11




12











13



14

















					
A FI 50 H-50-16	B 5x40 - 16	C FI 30 - 16	D M6x45 - 4	E x2	F x2

Service – Dienstverlening – Serwis – Servis – Сервисная служба – Assistenza - Szerviz







Typ – Type – Tip – Тип – Тірүс - Tipo

A	
B	
C	
D	
E	
F	








D – Recycling-Anweisungen
GB – Recycling instructions
NL – Instructies voor recycling
PL – Instrukcja recyklingu
TR – Geri dönüşüm talimatları
RU – Инструкции по переработке

RO – Instrucțiuni de reciclare
IT – Istruzioni per il riciclaggio
FR – Instructions de recyclage
SK – Pokyny na recykláciu
CZ – Pokyny k recyklaci
HU – Újrahasznosítási utasítások



D – Bedienungsanleitung
GB – Instruction manual
NL – Gebruiksaanwijzing
PL – Instrukcja obsługi
TR – Kullanım klavuzu
RU – ИНСТРУКЦИЯ ПО
 ЭКСПЛУАТАЦИИ

RO – Instrucțiuni de utilizare
IT – Manuale di istruzioni
FR – Manuel instructions
SK – Návod na použitie
CZ – Návod k použití
HU – Kezelési utasítás



D – Bedienungsanleitung
GB – Instruction manual
NL – Gebruiksaanwijzing
PL – Instrukcja obsługi
TR – Kullanım klavuzu
RU – ИНСТРУКЦИЯ ПО
 ЭКСПЛУАТАЦИИ

RO – Instrucțiuni de utilizare
IT – Manuale di istruzioni
FR – Manuel instructions
SK – Návod na použitie
CZ – Návod k použití
HU – Kezelési utasítás